

The All-Fabric D-Fuser is a textile air dispersion device designed for critical airflow applications. It is available in standard sizes of 2x4 and 2x8 and features a removable fabric face that simplifies installation and maintenance.

Your shipment includes the following:

- Fabric assembly
- Snap frame
- Inlet collar
- 4 each: T-bar clips, rivets, and S clips

### Equipment Required:

- Drill
- Rivet gun
- Screwdriver



## Installation Steps

### Step 1

Review materials in box, including the CAD drawing and installed location of the DuctSox. READ INSTRUCTIONS THOROUGHLY.

### Step 2

When placing the air supply location, note the Inlet on the D-Fuser is centered. See E on Figure 1.

### Step 3

The air supply must be a 16" diameter hard pipe to connect the fabric inlet collar.


### Step 4

The correct length of air supply hard pipe must be 2–3" above the ceiling.

### Step 5

Remove D-Fuser from packaging, separate the fabric body from the frame.

Note: Please keep the fabric body in the plastic cover until assembly. It is important to have clean hands anytime you handle the face fabric. If frame is 2x8, it will arrive in two pieces.



Module Size	A	B	C	D	E
2x4	48 7/8" (1241mm)	51 5/8" (1311mm)	25" (635mm)	27 1/2" (699mm)	16" (406mm)
2x8	96 7/8" (2461mm)	99 5/8" (2530mm)	25" (635mm)	27 1/2" (699mm)	16" (406mm)

## Step 6

Mount the frame to the ceiling.

### Three Scenarios

#### Scenario 1:

If inlet is squared in grid




Figure 2




Figure 3

#### Scenario 2:

If inlet is off-set or is not running with grid



A. Scenario 1: If inlet is squared in grid (Figure 2)

T-bar ceiling, hinged side

- Place S-clip on snap frame. See Figure 3.
- Hook snap frame onto T-bar grid. See Figure 4.
- Hinge up opposite side and attach T-bar clips. See Figure 5.




Figure 4



Figure 5

B. Scenario 2: If inlet is off-set or is not running with grid (Figure 6)

T-bar ceiling

- Use four T-bar twist clips to attach snap frame. See Figures 7 & 8.



Figure 6




Figure 7



Figure 8

### C. Scenario 3: Finished ceiling

- Hardware attachment by others: attach to ceiling stud or use an approved ceiling anchor (screws, bolts, etc.).

#### Step 7

Attach the D-Fuser inlet collar.

NOTE: It is important to have clean hands anytime you handle the face fabric.

- Slide fabric inlet collar over metal connection 3–5". Ensure zipper aligns flush with frame. See Figures 9 & 10.
- Critical step: To prevent twisting, test fit velcro.
- Align zipper start/stop with long side of D-Fuser frame orientation & proper depth.
- Tighten belt/Ductbuckle.
- Secure all anchor pads with standard self tapping screws. See Figure 11.
- Remove inlet tag



Figure 9



Figure 10



Figure 11

#### Step 8

Final assembly.

- Press D-Fuser velcro tight to the frame. See Figures 12 & 13.
- Secure grips. See Figure 14.



Figure 12



Figure 13




Figure 14

- Adjust as needed pulling taut to remove wrinkles
- When satisfied with the fit, close the frame by snapping shut. See Figures 15 & 16.



Figure 15



Figure 16

### Maintenance

- For maintenance, pull snap frame open on all four sides and disconnect grips on all four sides.
- Starting in a corner, remove the fabric face.
- Install clean or new face by aligning to hook and loop, securing anchor grips, and close the snap frame.

### Laundering Instructions

- To launder, soak in cold water for 30 minutes.
- Wash cold, gentle cycle.
- Rinse thoroughly (repeat cycle if water/DuctSox still soiled).
- Drip dry or no-heat tumble dry.



If any questions arise regarding the installation of your Critical Environments All-Fabric D-Fuser, contact us.

**866-382-8769 or 563-588-5300**

**DUCTSOX**<sup>®</sup>  
*Textile Air Dispersion Products*

9866 Kapp Court ■ Peosta, IA 52068  
Ph: 866-382-8769 or 563-588-5300 ■ Fax: 563-588-5330  
[www.ductsox.com](http://www.ductsox.com)

© 2014 DuctSox Corp.  
DSCEAFIG0114A